

F9 Variable Voltage Passthrough Operation

Plug the passthrough to the Power supply (computer or A/C to USB adapter): The blue LED flashes 3 times, Then install your atomizing device.

Smoking: Push the button and inhale, the blue / pink / red LED light will light up the color that the passthrough voltage is set at. Release the button to stop operation.

Smoking timeout: If you take a drag that lasts more than eight seconds the electronic program shuts the power to the atomizer off and the blue / pink / red LED light flashes 8 times.

Voltage switching: Press the button 5 times, interval no more than 5ms. The electronic passthrough will switch to the next output voltage (3.2V/3.7V/4.2V, blue / pink / red) and the LED light will flash 5 times in the color of voltage selected.

Smoking output short circuit protection: If the heating wire of the atomizer short-circuits during the smoking process, the electronic passthrough will automatically turn off the power to the atomizer and the blue / pink / red led light will flash 3 times.

CE4 Clearomizer Filling Instructions

To fill the CE4 remove the mouthpiece by turning counterclockwise and pulling it off the body. Then insert the needle tip or drip tip between the body and silicone stop. Fill to the bottom of the silicone stop with your e-liquid. Remove the needle tip or drip tip and replace the mouthpiece by pushing in and tighten clockwise.

Wait several minutes for the wick to get liquid to the heating coil before use. During use tip the CE4 back to keep the wick wet occasionally.

